

THE **AIR-O-SPACE™**

INSTANT BED IN A BAG



INSTRUCTIONS FOR USE

*Congratulations on purchasing the **AIR-O-SPACE INSTANT BED IN A BAG** - The future in Space Saving Sleep comfort. To help ensure years of trouble-free use, please take time to read these instructions.*

AIR-O-SPACE CONTENTS:

- 1 AIR-O-SPACE BED
- 1 AIR-O-SPACE DUAL ACTION TURBO PUMP
- 3 DIFFERENT-SIZE PUMP NOZZLES
- 1 HANDY CARRY BAG
- 2 AIR-O-SPACE PILLOWS
- 1 REPAIR KIT

INFLATING & DEFLATING




Inflate

Inflate the **AIR-O-SPACE BED** right after purchase and leave inflated for 8 hours before use.

The **DUAL-ACTION TURBO PUMP** can both inflate and deflate your **AIR-O-SPACE BED** and comes with 3 adaptable nozzles that can be used for your **AIR-O-SPACE BED** and other types of inflatables - pool accessories, etc. It also comes with an attachable handle. To fit, simply slide the handle into the slot on the side of the pump.



2-Way Air Valve



Deflate

Your **AIR-O-SPACE BED** has a 2-Way Air Valve that can be used for Express Inflation, Super Express Inflation and Deflation.

Express Inflation - Unscrew the top cap of the bed, insert the medium nozzle of the pump marked "INFLATE", then turn on the pump. Turn off the pump when desired firmness is reached.

Super Express Inflation - Unscrew the removable one-way valve, insert the large nozzle of the pump marked "INFLATE", then turn on the pump. Turn off the pump when desired firmness is reached.

Express Deflation - Unscrew the the removable one-way valve, insert the nozzle of the pump marked "DEFLATE", then turn on the pump. Turn off the pump when the **AIR-O-SPACE BED** is fully deflated.



Dual-Action Turbo Pump




Deflate

IMPORTANT:

1. Follow all instructions.
2. Never leave the **DUAL-ACTION TURBO PUMP** unattended while in use.
3. Never operate the **DUAL-ACTION TURBO PUMP** in wet conditions.
4. Do not allow sand and small rocks etc. to be sucked into the inflation or deflation ports while operating.
5. Never point or look directly into the inflation port while the pump is operating.
6. Do not attempt to place objects or body parts into the inflation port at any time.
7. The **DUAL-ACTION TURBO PUMP** is designed to fit the electrical supply in your country. Do not attempt to change the plug without consulting a qualified electrician.
8. **WARNING** - to reduce the risk of electric shock, do not expose the **DUAL-ACTION TURBO PUMP** to water. Store indoors.
9. Check that your power supply is the same as indicated on your **DUAL-ACTION TURBO PUMP**.
10. This is a high volume, low pressure pump. It is intended to be used for the inflation and deflation of your **AIR-O-SPACE BED**.
11. This pump is not designed for continuous use. Extended operation can cause over heating and damage the pump. Do not exceed 30 minutes of continuous operation.
12. Electrical equipment should only be operated by adults.

NOTE: When using the **AIR-O-SPACE BED** outdoors or in areas with no available electrical outlets, the **AIR-O-SPACE BED** can easily be pumped up by normal hand or foot pumps available in hardware stores.




ADJUSTING FIRMNESS

The **AIR-O-SPACE BED** is fully adjustable from firm to plush with the **AIR-O-SPACE Single Touch Comfy Control** (found on the left side of bed when directly facing the air intake valve). Simply uncap and give a little squeeze at the base of the valve to let air out for softer sleep comfort.

FOLDING & STORING

1. After deflating, do not re-insert one-way valve until folding is completed. Fold from the long sides of the **AIR-O-SPACE BED**, 1/3 of the way towards the center (see diagram).
2. Fold once more so that the edges meet the center.
3. Roll up as tightly as possible starting from the end directly opposite the air intake valve. When fully rolled up, the bed should easily fit into the **AIR-O-SPACE Handy Carry Bag**, ready for storage.



CARE & MAINTENANCE

1. Check the air level of the **AIR-O-SPACE BED** occasionally. If more than one person is using the **AIR-O-SPACE BED** at the same time, less air may be required for comfort. Experience will suggest the best air levels.
2. If used on water, make sure the velour surface is top-side up.
3. In case of the velour gets wet or dirty, clean it thoroughly with soap and water before letting it air dry. Do not use chemicals, scouring powder or any other abrasive.
4. Avoid exposing the **AIR-O-SPACE BED** to extreme temperatures. Inflate at room temperature.
5. Avoid over-inflating the **AIR-O-SPACE BED**.
6. Be careful of sharp objects that can damage the bed's material.

REPAIRING PIN-SIZED HOLES

1. Deflate the bed and replace the valve cap.
2. Apply repair glue (included in repair kit) to the tip of toothpick or pin and insert into the puncture.
3. Allow the glue to set, making sure the puncture is fully covered.
4. Apply a small amount of glue directly on top of the puncture.
5. Leave for at least four (4) hours before reinflating.

REPAIRING RIPS OR TEARS

1. After deflating the bed and replacing the cap, cut a piece of patching material (included in repair kit) large enough to overlap the rip or tear.
2. Apply the glue to the damaged area and press on the patch. Add more glue as needed to the sides of the patch and apply pressure to ensure proper and flawless bonding to the material of the bed.
3. Leave for at least four (4) hours before reinflating.



GENERAL CAUTION: Using any type of inflatable item in the water does not guarantee safety. Do not use the **AIR-O-SPACE BED** as a floatation device or life preserver. The **AIR-O-SPACE BED** is not recommended for use in open water. Children should be supervised at all times. Never allow diving into the product. Never leave in or near the water when not in use. Do not drink alcohol in or near pool or body of water. Please employ appropriate precautions. Follow these rules to avoid drowning, paralysis or other serious injury.



Homemark (Pty) Limited

39 Commerce Crescent, Eastgate Extension, Sandton, 2148 / Tel: (011) 444 3344 / Fax: (011) 444 0818